

HUMIDITY – TEMPERATURE DATA LOGGER



MINI TEMPERATURE AND HUMIDITY DATA LOGGER has internal Temperature & Humidity Sensor, and with optional external temperature sensor, with internal buzzer alarm. If external temperature sensor is connected, temperature measuring will automatically switch to the external temperature sensor. Display Temperature and Humidity , time , over limit alarm, temperature/humidity upper/ lower limit, temperature Max/Min. value in the LCD Screen. It has one CR2450 battery, with the battery compartment at the back, ease of battery replacement: Rotate the battery cover clockwise to remove the battery by a coin, and rotate and tighten the battery cover counter clockwise after battery replacement.

Directly connect with computer for data exchange, easy operation. It could also be powered by USB cable when connected with PC, and it could upload data even if the battery is out of use. Permanent data storage, data could be read and printed by PC data management software.

This Data Logger is mainly used for Temperature and Humidity recording during storage and transportation of foodstuff, medicine, chemicals and other products, especially widely used in all kinds of warehousing, logistics and cold chain, such as refrigerated containers, refrigerated trucks, refrigerated package, cold storage, laboratory , etc.

Contd...2....

...2....

Specifications:

Temperature Measuring range	-30 °C ... +60°C; For Optional External sensor, -40°C...+85 °C
Accuracy	For -30 °C ... +60°C : +/- 0.6 °C ; Others: +/- 1.2 °C
Temperature Unit	°C or °F Optional, set Through RC-4H Data Management Software
Humidity Measuring Range	0 ... 99% RH
Humidity Accuracy	+/- 3% RH (25°C, 20-90%RH), Others,+/-5% RH;
Resolution	Temperature: 0.1°C Humidity : 0.1% RG
Record Capacity	16000 points (MAX)
Record Interval	10 sec24 Hrs Adjustable
Communication Interface	USB Interface
Power Supply	Inner CR2450 battery or Power Supply via USB Interface
Battery Life	In Normal Temperature , if the record interval sets as 15 minutes, it could be used above one year
Product size	84mm (length) X 44mm (width) X 20 mm (height)
Software:	USB cable and Data Management software on CD supplied with the data logger

Distributed By :

ACE INSTRUMENTS

(An ISO 9001-2008 Certified Company)

Plot No.77, Shaktipuram, Industrial Estate Kukatpally, Prashantinagar,
Hyderabad - 500072. India.

Phones : 040-23078848, 32901226 , 23830848 Fax : 040-23078848

Email : sales@alwaysace.com ; info@alwaysace.com

Website : www.alwaysace.com